

Auto-Tune Reset

Most current Auto-Tune saws:

- Start the saw and run it in the Cold start position for at least 90secs.
- Do not touch the throttle or accelerate the saw during this time.
- After 90 seconds, the machine should be switched off
- Your saw is now re-calibrated and ready for operation.