



## HUSQVARNA LC 141iV

Ideal for homeowners or for cutting complex areas, this intuitive hassle-free battery mower can mow an average-sized garden quickly and quietly in a single charge. The mower is easy to manoeuvre due to its lightweight and compact deck and ergonomic handle makes it easy to steer even round small places. Compatible with all Husqvarna BLi-batteries.

### savE™

Choose between normal or savE™ mode, depending on conditions, for maximum power or maximum runtime. Either way, you'll always get a perfect result.



**Self-propelling with rear-wheel drive**

### Variable drive speed

Easy to adjust the ground speed according to your needs and the condition of the lawn.



### Intuitive key pad

The key pad is very easy to operate. All information you need in one place



## FEATURES

- Variable drive speed for easy speed adjustment
- Self-propelling with rear-wheel drive
- Choose savE™ mode for maximum runtime
- Intuitive key pad for easy operation
- Li-ion power, long lasting power and top class performance.
- Quiet operation
- Lifting handle front and rear
- Ergonomic handlebar
- Easy foldable handle bar
- Easy adjustable handle bar
- Central cutting height adjustment
- Cordless freedom

Technical specifications	
<b>CUTTING DECK</b>	
BioClip® kit	Available as accessory
Cutting height adjustment	Central
Cutting height steps	10
Cutting methods	Collection/Rear discharge
Cutting width	41 cm
<b>DIMENSIONS</b>	
Weight	21.5 kg
Wheel size, Front	170 mm
Wheel size, Rear	203 mm
<b>DRIVE SYSTEM</b>	
Drive system	Self-propelled, variable speed
Drive wheels	Rear
<b>ENGINE</b>	
Net power at preset rpm Energy	0.55 kW
<b>EQUIPMENT</b>	
Collector type	Hard top with fabric bag
Collector volume	50.0 l
Foldable handlebar	Yes
Handle type	Ergonomic
Soft grip	Yes
Wheel bearing, front/rear	yes/yes
<b>MATERIAL</b>	
Cutting deck material	Steel
Rims, material	Plastic
<b>SOUND AND NOISE</b>	
Sound power level, guaranteed (LWA)	94 dB(A)
Sound power level, measured	92 dB(A)
Sound pressure level at operators ear	83 dB(A)

## ACCESSORIES



HUSQVARNA BATTERY CHARGER  
QC80  
967 33 56-51



HUSQVARNA BLI300 BATTERY  
9.4AH  
967 07 19-01



HUSQVARNA CHARGER QC500  
967 09 15-02

HUSQVARNA BATTERY CHARGER  
QC80F  
967 62 83-01



HUSQVARNA BATTERY CHARGER  
QC330 330W  
967 09 14-02



HUSQVARNA BATTERY BLI200  
5.2AH  
967 09 19-01



HUSQVARNA BATTERY BLI20  
4.0AH  
967 09 17-01