

Most current M-Tronic saws:

- Start the saw and run it in the ▲ Cold start position for at least 90secs.
- Do not touch the throttle or accelerate the saw during this time.
- After 90 seconds, the machine should be switched off
- Your saw is now re-calibrated and ready for operation.

For MS 462 C-M and future saws there is a different reset procedure:

- Start the saw and run it in the ▲ cold start for at least 30 seconds but no more than 60 seconds
- Pull the throttle fully for at least 30 seconds.
- Engine speed varies.
- As soon as the engine speed drops noticeably (C), release the throttle
- Your saw is now re-calibrated and ready for operation.

